

FOOL PROOF QUICK GUIDE FOR COLLAPSE

To get into Settings:

Press program button screen will come up to input password 0000 hit enter.

1: Screen will appear and say "Side by Side" = for hooking up 2 units Right and left Side

2: Down arrow will take you to "Sensitive Level" press enter this will change sensitivity

Right 1 (default 210) L- to lower R+ to raise

Right 2 (default 210) L - to lower R+ to raise

Right 3 (default 210) L- to lower R+ to raise

Left 1 (default 210) L - to lower R+ to raise

Left 2 (default 210) L - to lower R+ to raise

Left 3 (default 210) L- to lower R+ to raise

3: Down arrow will take you to "Factory Reset" = put unit back to Factory settings

Hit enter

4: Down arrow will take you to screen "Frequency Set" = only change when hooking multiple units up

Hit enter

L- to lower R+ to raise

5: Down arrow will take you to "Change Password" this is where to change password

6: Down arrow will take you to "Setting Louder" = This makes speaker louder or quieter

Hit enter

L- to lower R+ to raise

Down arrow will take you to "QSS" this setting will self-calibrate the machine